

SecurityLab 4K Action Spy Camera Sunglasses (UV400) User Manual

Introduction

Thank you for purchasing the 4K Action Spy Camera Sunglasses. This manual provides general guidance for safe use and care.

Package Contents

- Camera sunglasses
- USB Type-C charging cable
- Protective case (if included)
- Cleaning cloth (if included)

Specifications

Resolution: Up to 4K video (per product listing)

Photos: Up to 24 MP

Storage: 32 GB internal memory

Video format: MP4 (H.265)

Battery: Rechargeable 500 mAh

Lens: UV400

Charging

Charge the device using the supplied USB Type-C cable and a standard 5V USB power source until fully charged.

File Transfer

Connect the sunglasses to a Windows or macOS computer using USB. The internal storage should appear as removable storage for copying video and photo files.

Care

Keep lenses clean with a microfiber cloth. Avoid water, extreme heat, and impacts.

Safety

Use only in accordance with local laws. Respect privacy and obtain consent where required.

Troubleshooting

If the device is not recognized, try another USB port/cable and ensure the battery has sufficient charge. If recording issues occur, free storage space and recharge the battery.

Support

For product support, contact SecurityLab through the retailer from which the product was purchased.